

NOTE:
 Light circuit wiring, door switch and alarm wiring @ latch side of door frame by field electrician (NIC).
 See alarm mfg for wiring diagrams

IMPERIAL MFG
 PORTLAND OR
 503-665-5539
 REV 2 : 1/16/05

